

## Ultrareine PFA-Membranventile HPW

**Durchgangsventile** 1/4" - 1 1/4" (DN 4 - 25)

**T-Ventile** 1/4" - 1 1/4" (DN 6 - 25) (Durchgang) / 1/4" - 1 1/4" (DN 4 - 25) (Abgang)

## PP-Membranventile HPS

**Durchgangsventile** 1/2" - 1 1/4" (DN 10 - 32)

## Ultrareine PVDF Membranventile

**Durchgangsventile** 1/2" (DN 15)

## Ultra Pure PFA Diaphragm Valves HPW

**2/2 Way Valves** 1/4" - 1 1/4" (DN 4 - 25)

**T Valves** 1/4" - 1 1/4" (DN 6 - 25) (Main pipe) / 1/4" - 1 1/4" (DN 4 - 25) (Branch)

## PP Diaphragm Valves HPS

**2/2 Way Valves** 1/2" - 1 1/4" (DN 10 - 32)

## Ultra Pure PVDF Diaphragm Valves

**2/2 Way Valves** 1/2" (DN 15)

Ⓓ ORIGINAL EINBAU- UND MONTAGEANLEITUNG  
ⒼB INSTALLATION, OPERATING AND  
MAINTENANCE INSTRUCTIONS



# Inhaltsverzeichnis


<b>1</b>	<b>Allgemeine Hinweise</b>	<b>2</b>
<b>2</b>	<b>Allgemeine Sicherheitshinweise</b>	<b>2</b>
2.1	Hinweise für Service- und Bedienpersonal	2
2.2	Warnhinweise	3
2.3	Verwendete Symbole	3
<b>3</b>	<b>Begriffsbestimmungen</b>	<b>4</b>
<b>4</b>	<b>Vorgesehener Einsatzbereich</b>	<b>4</b>
<b>5</b>	<b>Lieferumfang</b>	<b>4</b>
<b>6</b>	<b>Technische Daten</b>	<b>4</b>
<b>7</b>	<b>Bestelldaten</b>	<b>10</b>
<b>8</b>	<b>Herstellerangaben</b>	<b>11</b>
8.1	Transport	11
8.2	Lieferung und Leistung	11
8.3	Lagerung	11
8.4	Benötigtes Werkzeug	11
8.5	Öffnen der Verpackung	11
<b>9</b>	<b>Funktionsbeschreibung</b>	<b>12</b>
9.1	Typenschild	12
<b>10</b>	<b>Geräteaufbau</b>	<b>12</b>
<b>11</b>	<b>Montage und Bedienung</b>	<b>13</b>
11.1	Montage des Membranventils	13
11.2	Bedienung	14
11.3	Einstellung der Schließbegrenzung	15
11.4	Handradsicherung	16
<b>12</b>	<b>Inbetriebnahme</b>	<b>16</b>
<b>13</b>	<b>Inspektion und Wartung</b>	<b>17</b>
<b>14</b>	<b>Demontage</b>	<b>17</b>
<b>15</b>	<b>Entsorgung</b>	<b>17</b>
<b>16</b>	<b>Rücksendung</b>	<b>17</b>
<b>17</b>	<b>Hinweise</b>	<b>18</b>
<b>18</b>	<b>Fehlersuche / Störungsbehebung</b>	<b>18</b>
<b>19</b>	<b>EU-Konformitätserklärung</b>	<b>19</b>


## 1 Allgemeine Hinweise

Voraussetzungen für die einwandfreie Funktion des GEMÜ-Ventils:

- x Sachgerechter Transport und Lagerung
- x Installation und Inbetriebnahme durch eingewiesenes Fachpersonal
- x Bedienung gemäß dieser Einbau- und Montageanleitung
- x Ordnungsgemäße Instandhaltung

Korrekte Montage, Bedienung und Wartung oder Reparatur gewährleisten einen störungsfreien Betrieb des Membranventils.

	Beschreibungen und Instruktionen beziehen sich auf Standardausführungen. Für Sonderausführungen, die in dieser Einbau- und Montageanleitung nicht beschrieben sind, gelten die grundsätzlichen Angaben in dieser Einbau- und Montageanleitung in Verbindung mit einer zusätzlichen Sonderdokumentation.
---	---

	Alle Rechte wie Urheberrechte oder gewerbliche Schutzrechte werden ausdrücklich vorbehalten.
---	--

## 2 Allgemeine Sicherheitshinweise

Die Sicherheitshinweise berücksichtigen nicht:

- x Zufälligkeiten und Ereignisse, die bei Montage, Betrieb und Wartung auftreten können.
- x die ortsbezogenen Sicherheitsbestimmungen, für deren Einhaltung - auch seitens des hinzugezogenen Montagepersonals - der Betreiber verantwortlich ist.

### 2.1 Hinweise für Service- und Bedienpersonal

Die Einbau- und Montageanleitung enthält grundlegende Sicherheitshinweise, die bei Inbetriebnahme, Betrieb und Wartung zu beachten sind. Nichtbeachtung kann zur Folge haben:

- x Gefährdung von Personen durch elektrische, mechanische und chemische Einwirkungen.
- x Gefährdung von Anlagen in der Umgebung.
- x Versagen wichtiger Funktionen.
- x Gefährdung der Umwelt durch Austreten

- gefährlicher Stoffe bei Leckage.
- x Gefährdung der Prozessreinheit und / oder der Prozesssicherheit.

**Vor Inbetriebnahme:**

- Einbau- und Montageanleitung lesen.
- Montage- und Betriebspersonal ausreichend schulen.
- Sicherstellen, dass der Inhalt der Einbau- und Montageanleitung vom zuständigen Personal vollständig verstanden wird.
- Verantwortungs- und Zuständigkeitsbereiche regeln.

**Bei Betrieb:**

- Einbau- und Montageanleitung am Einsatzort verfügbar halten.
- Sicherheitshinweise beachten.
- Nur entsprechend der Leistungsdaten betreiben.
- Wartungsarbeiten bzw. Reparaturen, die nicht in der Einbau- und Montageanleitung beschrieben sind dürfen nicht ohne vorherige Abstimmung mit dem Hersteller durchgeführt werden.

<b>⚠ GEFAHR</b>
<b>Sicherheitsdatenblätter bzw. die für die verwendeten Medien geltenden Sicherheitsvorschriften unbedingt beachten!</b>

**Bei Unklarheiten:**

- x Bei nächstgelegener GEMÜ-Verkaufsniederlassung nachfragen.

## 2.2 Warnhinweise

Warnhinweise sind, soweit möglich, nach folgendem Schema gegliedert:

<b>⚠ SIGNALWORT</b>
<b>Art und Quelle der Gefahr</b>
<ul style="list-style-type: none"> <li>➤ Mögliche Folgen bei Nichtbeachtung.</li> <li>● Maßnahmen zur Vermeidung der Gefahr.</li> </ul>

Warnhinweise sind dabei immer mit einem Signalwort und teilweise auch mit einem gefahrenspezifischen Symbol gekennzeichnet.

Folgende Signalwörter bzw. Gefährdungsstufen werden eingesetzt:







<b>⚠ GEFAHR</b>
<b>Unmittelbare Gefahr!</b>
➤ Bei Nichtbeachtung sind Tod oder schwerste Verletzungen die Folge.

<b>⚠ WARNUNG</b>
<b>Möglicherweise gefährliche Situation!</b>
➤ Bei Nichtbeachtung drohen schwerste Verletzungen oder Tod.

<b>⚠ VORSICHT</b>
<b>Möglicherweise gefährliche Situation!</b>
➤ Bei Nichtbeachtung drohen mittlere bis leichte Verletzungen.

<b>VORSICHT (OHNE SYMBOL)</b>
<b>Möglicherweise gefährliche Situation!</b>
➤ Bei Nichtbeachtung drohen Sachschäden.

## 2.3 Verwendete Symbole

	Gefahr durch heiße Oberflächen!
	Gefahr durch ätzende Stoffe!
	Hand: Beschreibt allgemeine Hinweise und Empfehlungen.
	Punkt: Beschreibt auszuführende Tätigkeiten.
	Pfeil: Beschreibt Reaktion(en) auf Tätigkeiten.
	Aufzählungszeichen

### 3 Begriffsbestimmungen

#### Betriebsmedium

Medium, das durch das Membranventil fließt.

### 4 Vorgesehener Einsatzbereich

- x Das GEMÜ-Membranventil CleanStar® C67 ist für den Einsatz in Rohrleitungen konzipiert. Es steuert ein durchfließendes Medium durch Handbetätigung.
- x **Das Ventil darf nur gemäß den technischen Daten eingesetzt werden (siehe Kapitel 6 "Technische Daten").**
- x Schrauben und Kunststoffteile am Membranventil nicht lackieren!

#### ⚠ WARNUNG

##### Membranventil nur bestimmungsgemäß einsetzen!

- Sonst erlischt Herstellerhaftung und Gewährleistungsanspruch.
- Das Membranventil ausschließlich entsprechend den in der Vertragsdokumentation und in der Einbau- und Montageanleitung festgelegten Betriebsbedingungen verwenden.

### 5 Lieferumfang

Im Lieferumfang sind enthalten:

- x Membranventil
- x Bei Flare-Verbindung: Überwurfmuttern
- x Einbau- und Montageanleitung

Das GEMÜ-Membranventil wird als separat verpacktes Bauteil ausgeliefert.

### 6 Technische Daten

#### Betriebsmedium

Aggressive, neutrale, gasförmige und flüssige Medien, (HPW Version: insbesondere Reinstmedien) die die physikalischen und chemischen Eigenschaften des jeweiligen Gehäuse- und Membranwerkstoffes nicht negativ beeinflussen.

Verbesserte Durchflussleistungen bei High Flow-Ausführungen.

#### Betriebsdruck

Max. 6 bar einseitig anstehend

Vakuum 400 mbar/abs\*

\* Die Lebensdauer kann durch höheren Unterdruck oder bei pumpensaugseitig eingebauten Ventilen beeinträchtigt werden.

#### Durchflussrichtung

Beliebig

#### Betriebstemperatur

siehe Temperatur / Druck-Diagramme Seite 7

#### Umgebungstemperatur

Max. 60 °C (130 °F)

#### Materialien

Ausführung HPS: Mediumsbenetzte Teile (Körper)	PP
Ausführung HPW: Mediumsbenetzte Teile (Körper)	PFA
Ausführung PVDF: Mediumsbenetzte Teile (Körper)	PVDF
Membrane	PTFE
Antriebsteile außenliegend	PVDF
Ausführung HPW: Überwurfmutter (Antrieb-Körper), optional	ECTFE

#### Ausführung PVDF: Kv / Cv-Werte Durchgangsventile

Anschluss				Größe		Kv-Wert*	Cv-Wert
Größe		Anschlussart	Code	DN	Antrieb	l/min	US gal/min
1/2"	Rohr	Armaturenverschraubung	7, 78	15	2	68,0	4,7

\* Grundlage der Messung ist Wasser bei 5 bar Eingangsdruck und einer Temperatur von 20 °C.

**Ausführung HPW: Kv / Cv-Werte Durchgangsventile - Standard**

Anschluss						Kv	Cv	Antriebsgröße
Größe		Anschlussart	Code	Code intern.	DN	l/min	US gal/min	
1/4"	Schlauch	Flare-Anschluss	73, 75, 77	4	4	4	0,29	1
	Schlauch	Flare / Space Saver	73, 75, 77	4	4	4	0,29	1
	Schlauch	PrimeLock-Anschluss	PL	4	4	4	0,29	1
	Rohr	Schweißstutzen Zoll	30	4	10	15	1,05	1
3/8"	Schlauch	Flare-Anschluss	73, 75, 77	6	6	15	1,05	1
	Schlauch	Flare / Space Saver	73, 75, 77	6	6	15	1,05	1
	Schlauch	PrimeLock-Anschluss	PL	6	6	15	1,05	1
1/2"	Schlauch	Flare-Anschluss	73, 75, 77	8	10	35	2,45	2
	Schlauch	Flare / Space Saver	73, 75, 77	8	10	35	2,45	2
	Schlauch	Space Saver / Space Saver	73, 75, 77	8	10	35	2,45	2
	Schlauch	PrimeLock-Anschluss	PL	8	10	35	2,45	2
	Schlauch/Rohr	Flare / Schweißstutzen Zoll	30, 73, 75, 77	8	10/15	35	2,45	2
	Rohr	Schweißstutzen Zoll	30	8	15	68	4,76	2
3/4"	Schlauch	Flare-Anschluss	73, 75, 77	12	15	68	4,76	2
	Schlauch	Flare / Space Saver	73, 75, 77	12	15	68	4,76	2
	Schlauch	Space Saver / Space Saver	73, 75, 77	12	15	68	4,76	2
	Schlauch/Rohr	Flare / Schweißstutzen Zoll	30, 73, 75, 77	12	15/20	68	4,76	2
	Rohr	Schweißstutzen Zoll	30	12	20	68	4,76	2
	Schlauch	Flare-Anschluss	73, 75, 77	12	15	68	4,76	3
	Schlauch/Rohr	Flare / Schweißstutzen Zoll	30, 73, 75, 77	12	15/20	68	4,76	3
1"	Schlauch	Flare-Anschluss	73, 75, 77	16	20	158	11,06	3
	Schlauch	Flare / Space Saver	73, 75, 77	16	20	158	11,06	3
	Schlauch	Space Saver / Space Saver	73, 75, 77	16	20	158	11,06	3
	Schlauch/Rohr	Flare / Schweißstutzen Zoll	30, 73, 75, 77	16	20/25	160	11,20	3
	Rohr	Schweißstutzen Zoll	30	16	25	175	12,25	3
1 1/4"	Schlauch	Flare-Anschluss*	73, 75, 77	20	25	170	11,90	3

**Durchgangsventil - High Flow**

1/2"	Rohr	Schweißstutzen Zoll	30	8	15	115	7,99	2
3/4"	Schlauch	PrimeLock-Anschluss	PL	12	15	115	7,99	2
	Schlauch	Flare / Space Saver	73, 75, 77	12	15	115	7,99	2
	Schlauch	Space Saver / Space Saver	73, 75, 77	12	15	115	7,99	2
	Schlauch	Flare-Anschluss	73, 75, 77	12	15	115	7,99	2
	Rohr	Schweißstutzen Zoll	30	12	20	115	7,99	2
1"	Schlauch	PrimeLock-Anschluss	PL	16	20	123	8,57	2
	Schlauch	Flare-Anschluss	73, 75, 77	16	20	123	8,57	2
	Rohr	Schweißstutzen Zoll	30	16	25	123	8,57	2
	Schlauch	PrimeLock-Anschluss	PL	16	20	316	21,99	3
	Schlauch	Flare-Anschluss	73, 75, 77	16	20	316	21,99	3
	Rohr	Schweißstutzen Zoll	30	16	25	316	21,99	3
1 1/4"	Schlauch	PrimeLock-Anschluss	PL	20	25	170	11,90	3
	Schlauch	Flare-Anschluss	73, 75, 77	20	25	325	22,57	3

\* mit angeschweißten Stutzen auf Anfrage

**Kv / Cv-Werte Durchgangsventile**

Anschluss				Größe			Kv-Wert*	Cv-Wert
Größe		Anschlussart	Code	Code international	DN	Antrieb	l/min	US gal/min
1/2"	Schlauch	Flare-Anschluss	75	8	10	2	34,2	2,4
	Rohr	metrischer Schweißstutzen	20	-	15	2	82,5	5,7
3/4"	Schlauch	Flare-Anschluss	75	12	15	2	86,7	6,0
	Rohr	metrischer Schweißstutzen	20	-	20	2	83,7	5,8
	Rohr	metrischer Schweißstutzen	20	-	20	3	171,7	11,9
1"	Schlauch	Flare-Anschluss	75	16	20	2	93,3	6,5
	Rohr	metrischer Schweißstutzen	20	-	25	2	94,0	6,5
	Schlauch	Flare-Anschluss	75	16	20	3	183,3	12,7
	Rohr	metrischer Schweißstutzen	20	-	25	3	233,3	16,2
	Rohr	Armaturenverschraubung	78	-	25	3	233,3	16,2
1 1/4"	Schlauch	Flare-Anschluss	75	20	25	3	238,3	16,6
	Rohr	metrischer Schweißstutzen	20	-	32	3	238,3	16,6

\* Grundlage der Messung ist Wasser bei 5 bar Eingangsdruck und einer Temperatur von 20 °C.




**Ausführung HPW: Kv / Cv-Werte T-Ventile**


Durchgangsrohr X und Z											Abgang Y				Antrieb	Kv-Wert	Cv-Wert
Anschluss					Größe		Anschluss					Größe					
Größe		Anschlussart	Code	Code intern.	DN	Größe	Anschlussart	Code	Code intern.	DN	Größe	I/min	US gal/min				
1/4"	Rohr	Schweißstutzen Zoll	30	4	10	1/4" Rohr	Schweißstutzen Zoll	30	4	10	1						
3/8"	Schlauch	Flare-Anschluss	73, 75, 77	6	6	1/4" Schlauch	Flare-Anschluss	73, 75, 77	4	4	1						
	Schlauch	Flare-Anschluss	73, 75, 77	6	6	3/8" Schlauch	Flare-Anschluss	73, 75, 77	6	6	1						
1/2"	Schlauch	Flare-Anschluss	73, 75, 77	8	10	3/8" Schlauch	Flare-Anschluss	73, 75, 77	6	6	1	17	1,19				
	Schlauch	Flare / Space Saver	73, 75, 77	8	10	3/8" Schlauch	Flare-Anschluss	73, 75, 77	6	6	1	17	1,19				
	Schlauch	Flare-Anschluss	73, 75, 77	8	10	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	28	1,96				
	Schlauch	Flare / Space Saver	73, 75, 77	8	10	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	28	1,96				
	Schlauch	Space Saver / Flare	73, 75, 77	8	10	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	28	1,96				
	Rohr	Schweißstutzen Zoll	30	8	15	1/4" Rohr	Schweißstutzen Zoll	30	4	10	1						
	Rohr	Schweißstutzen Zoll	30	8	15	1/2" Rohr	Schweißstutzen Zoll	30	8	15	2						
3/4"	Schlauch	Flare-Anschluss	73, 75, 77	12	15	3/8" Schlauch	Flare-Anschluss	73, 75, 77	6	6	1	18	1,26				
	Schlauch	Space Saver / Flare	73, 75, 77	12	15	3/8" Schlauch	Flare-Anschluss	73, 75, 77	6	6	1	18	1,26				
	Schlauch	Flare / Space Saver	73, 75, 77	12	15	3/8" Schlauch	Flare-Anschluss	73, 75, 77	6	6	1	18	1,26				
	Schlauch	Flare-Anschluss	73, 75, 77	12	15	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	35	2,45				
	Schlauch	Flare / Space Saver	73, 75, 77	12	15	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	35	2,45				
	Schlauch	Space Saver / Flare	73, 75, 77	12	15	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	35	2,45				
	Schlauch	Space Saver	73, 75, 77	12	15	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	35	2,45				
	Schlauch	Flare-Anschluss	73, 75, 77	12	15	1/2" Schlauch	Space Saver	73, 75, 77	8	10	2	35	2,45				
3/4"	Schlauch	Flare-Anschluss	73, 75, 77	12	15	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	62	4,34				
	Schlauch	Space Saver / Flare	73, 75, 77	12	15	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	62	4,34				
	Schlauch	Flare / Space Saver	73, 75, 77	12	15	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	62	4,34				
	Schlauch	Flare-Anschluss	73, 75, 77	12	15	3/4" Schlauch	Space Saver	73, 75, 77	12	15	2	62	4,34				
	Rohr	Schweißstutzen Zoll	30	12	20	1/4" Rohr	Schweißstutzen Zoll	30	4	10	2						
	Rohr	Schweißstutzen Zoll	30	12	20	1/2" Rohr	Schweißstutzen Zoll	30	8	15	2	38	2,66				
	Rohr	Schweißstutzen Zoll	30	12	20	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	38	2,66				
1"	Rohr	Schweißstutzen Zoll	30	12	20	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	71	4,97				
	Schlauch	Flare-Anschluss	73, 75, 77	16	20	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	38	2,66				
	Schlauch	Space Saver / Flare	73, 75, 77	16	20	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	38	2,66				
	Schlauch	Flare / Space Saver	73, 75, 77	16	20	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	38	2,66				
	Schlauch	Space Saver	73, 75, 77	16	20	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	2	38	2,66				
	Schlauch	Flare-Anschluss	73, 75, 77	16	20	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	71	4,97				
	Schlauch	Space Saver / Flare	73, 75, 77	16	20	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	71	4,97				
	Schlauch	Flare / Space Saver	73, 75, 77	16	20	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	2	71	4,97				
	Schlauch	Flare-Anschluss	73, 75, 77	16	20	3/4" Schlauch	Space Saver	73, 75, 77	12	15	2	71	4,97				
	Schlauch	Flare-Anschluss	73, 75, 77	16	20	1" Schlauch	Flare-Anschluss	73, 75, 77	16	20	3	137	9,59				
	Schlauch	Space Saver / Flare	73, 75, 77	16	20	1" Schlauch	Flare-Anschluss	73, 75, 77	16	20	3	137	9,59				
	Schlauch	Flare / Space Saver	73, 75, 77	16	20	1" Schlauch	Flare-Anschluss	73, 75, 77	16	20	3	137	9,59				
	Rohr	Schweißstutzen Zoll	30	16	25	1/2" Rohr	Schweißstutzen Zoll	30	8	15	3						
	Rohr	Schweißstutzen Zoll	30	16	25	1/2" Rohr	Flare-Anschluss	73, 75, 77	8	10	3						
Rohr	Schweißstutzen Zoll	30	16	25	3/4" Rohr	Schweißstutzen Zoll	30	12	20	3							
Rohr	Schweißstutzen Zoll	30	16	25	1" Rohr	Schweißstutzen Zoll	30	16	25	3	135	9,45					
Rohr	Schweißstutzen Zoll	30	16	25	1" Schlauch	Flare-Anschluss	73, 75, 77	16	20	3							
1 1/4"	Schlauch	Flare-Anschluss	73, 75, 77	20	25	1/2" Schlauch	Flare-Anschluss	73, 75, 77	8	10	3	53	3,71				
	Schlauch	Flare-Anschluss	73, 75, 77	20	25	3/4" Schlauch	Flare-Anschluss	73, 75, 77	12	15	3	117	8,19				
	Schlauch	Flare-Anschluss	73, 75, 77	20	25	1" Schlauch	Flare-Anschluss	73, 75, 77	16	20	3	150	10,5				
	Schlauch	Flare-Anschluss	73, 75, 77	20	25	1 1/4" Schlauch	Flare-Anschluss	73, 75, 77	20	25	3	170	11,9				

Kv / Cv-Wert Flare-Anschluss  $\hat{=}$  Kv / Cv-Wert Space saver


## Temperatur / Druck - Diagramm Ventilkörperwerkstoff PFA (Ausführung HPW)



## Temperatur / Druck - Diagramm Ventilkörperwerkstoff PP (Ausführung HPS)



## Temperatur / Druck - Diagramm Ventilkörperwerkstoff PVDF (Ausführung HPW)



### Hinweis für den Gebrauch des Diagramms

Das Temperatur / Druck-Diagramm ist nur eine Orientierungshilfe. Die Angaben beziehen sich auf Wasser als Betriebsmedium. Änderungen der Betriebsbedingungen oder andere Medien können zu Abweichungen führen. Im Zweifelsfall ist es ratsam, mittels einer Probeinstallation das Verhalten des Materials unter den definitiven Betriebsbedingungen zu testen.

Temperaturen unter 0 °C können die Betätigungsgeschwindigkeit negativ beeinflussen.

VERFÜGBARKEIT CleanStar® C67 HPW DURCHGANGSVENTILE

Anschlussart / Verfügbarkeit							Größe			Abmessungen s. Datenblatt Seite
Flare-Anschluss	PrimeLock	Schweißstutzen		Flare-Anschluss / Space saver			Anschluss		Antrieb	
		beidseitig	einseitig Pos. Z	einseitig Pos. X	einseitig Pos. Z	beidseitig Pos. X + Z	Code internat.	DN		
1/4" - 1/4"	1/4" - 1/4"	1/4" - 1/4"			1/4" - 1/4"		4	4/10	1	9
3/8" - 3/8"	3/8" - 3/8"				3/8" - 3/8"		6	6		9
1/2" - 1/2"	1/2" - 1/2"	1/2" - 1/2" <sup>2)</sup>	1/2" - 1/2"		1/2" - 1/2"	1/2" - 1/2"	8	10	2	10
3/4" - 3/4" <sup>2)</sup>	3/4" - 3/4" <sup>1)</sup>		3/4" - 3/4"		3/4" - 3/4"	3/4" - 3/4"	8	10/15		10
		3/4" - 3/4" <sup>2)</sup>					12	15		10
1" - 1" <sup>1)</sup>	1" - 1" <sup>1)</sup>						12	20		10
							16	20		10
3/4" - 3/4"			3/4" - 3/4"				12	15	3	11
		3/4" - 3/4"					12	15/20		11
1" - 1" <sup>2)</sup>	1" - 1" <sup>1)</sup>				1" - 1"	1" - 1"	12	20		11
		1" - 1" <sup>2)</sup>					16	20		11
			1" - 1"				16	25		11
1 1/4" - 1 1/4" <sup>2)</sup>	1 1/4" - 1 1/4" <sup>1)</sup>				1 1/4" - 1 1/4" <sup>2)</sup>	1 1/4" - 1 1/4" <sup>2)</sup>	16	20/25	11	
							20	25	11	

<sup>1)</sup> nur High Flow Variante erhältlich

<sup>2)</sup> als High Flow Variante mit erhöhtem Kv-Wert erhältlich

VERFÜGBARKEIT CleanStar® C67 HPS DURCHGANGSVENTILE

Anschlussart / Verfügbarkeit							Antriebsgröße	Abmessungen siehe Seite C67
Flare-Anschluss	Schweißstutzen		Armaturenverschraubung	Anschluss				
	beidseitig	einseitig Pos. Z		Code international	DN			
1/2" - 1/2"				8	10	2	7	
	15 - 15			-	15		7	
3/4" - 3/4"				12	15		7	
	20 - 20			-	20		7	
1" - 1"				16	20		7	
	25 - 25			-	25		7	
	20 - 20			-	20	3	7	
1" - 1"				16	25		7	
	25 - 25			-	25		7	
			25 - 25		25		8	
1 1/4" - 1 1/4"				20	25		7	
	32 - 32			-	32	7		




VERFÜGBARKEIT CleanStar® C67 HPW T-VENTILE

Anschlussart / Verfügbarkeit					Größe				Antrieb	Abmessungen siehe Datenblatt Seite
Flare-Anschluss	Flare-Anschluss / Space saver				Anschluss					
	Durchgangsrohr				Durchgangsrohr X + Z		Abgang Y			
	Pos. X	Pos. Z	Pos. X + Z	Pos. Y	Code international	DN	Code international	DN		
3/8" 1/4" 3/8"					6	6	4	4	1	12
3/8" 3/8" 3/8"					6	6	6	6		12
1/2" 3/8" 1/2"		1/2" 3/8" 1/2"			8	10	6	6		12
3/4" 3/8" 3/4"	3/4" 3/8" 3/4"	3/4" 3/8" 3/4"			12	15	6	6		12
1/2" 1/2" 1/2"		1/2" 1/2" 1/2"		1/2" 1/2" 1/2"	8	10	8	10	2	13/14
					8	15	8	15		13/14
					8	15	8	10		13/14
3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	12	15	8	10		13/14
					12	20	4	8		13/14
3/4" 3/4" 3/4"	3/4" 3/4" 3/4"	3/4" 3/4" 3/4"		3/4" 3/4" 3/4"	12	15	12	15		13/14
1" 1/2" 1"	1" 1/2" 1"	1" 1/2" 1"	1" 1/2" 1"		16	20	8	10		13/14
1" 3/4" 1"	1" 3/4" 1"	1" 3/4" 1"		1" 3/4" 1"	16	20	12	15		13/14
					16	25	8	15	3	15
					16	25	12	20		15
					16	25	16	25		15
1" 1" 1"	1" 1" 1"	1" 1" 1"			16	20	16	20		15
1 1/4" 1/2" 1 1/4"		1 1/4" 1/2" 1 1/4"			20	25	8	10		15
1 1/4" 3/4" 1 1/4"		1 1/4" 3/4" 1 1/4"			20	25	12	15		15
1 1/4" 1" 1 1/4"		1 1/4" 1" 1 1/4"			20	25	16	20		15
1 1/4" 1 1/4" 1 1/4"		1 1/4" 1 1/4" 1 1/4"			20	25	20	25		15

VERFÜGBARKEIT CleanStar® C67 HPW T-VENTILE

Anschlussart / Verfügbarkeit				Größe				Antrieb	Abmessungen siehe Datenblatt Seite
Schweißstutzen	Schweißstutzen / Flare-Anschluss	Schweißstutzen / Space saver	Schweißstutzen / Flare-Anschluss	Anschluss					
				Durchgangsrohr X + Z		Abgang Y			
				Code international	DN	Code international	DN		
1/4" 1/4" 1/4"				4	10	4	10	1	12
1/2" 1/4" 1/2"				8	15	4	8		12
1/2" 1/2" 1/2"				8	15	8	15	2	13/14
		1/2" 1/2" 1/2"	1/2" 1/2" 1/2"	8	15	8	10		13/14
	3/4" 1/2" 3/4"			12	20	8	10		13/14
	3/4" 3/4" 3/4"			12	20	12	15		13/14
3/4" 1/4" 3/4"				12	20	4	8		13/14
3/4" 1/2" 3/4"				12	20	8	15		13/14
1" 1/2" 1"								3	15
1" 3/4" 1"									15
1" 1" 1"									15
	1" 1/2" 1"	1" 1/2" 1"		16	25	8	10		15
	1" 1" 1"	1" 1" 1"		16	25	10	20		15

## 7 Bestelldaten

Position Space saver <sup>1</sup> (für D-Körper)		Code
Space saver in z-Position		Z
Space saver in x+z-Position		S

Position Schweißstutzen <sup>1</sup> (für D-Körper)		Code
Flare in x, Schweißstutzen in z		K

Position Space saver <sup>1</sup> (für T-Körper)		Code
Space saver in y-Position		Y

Nennweite*		Code
1/4" Schlauch <sup>1</sup>	DN 4	4
3/8" Schlauch <sup>1</sup>	DN 6	6
1/2" Schlauch	DN 10	8
1/2" Rohr	DN 15	8
3/4" Schlauch	DN 15	12
3/4" Rohr <sup>1</sup>	DN 20	12
Rohr <sup>2</sup>	DN 15	15
1" Schlauch	DN 20	16
1" Rohr <sup>1</sup>	DN 25	16
1 1/4" Schlauch	DN 25	20
Rohr <sup>2</sup>	DN 20	20
Rohr <sup>2</sup>	DN 25	25
Rohr <sup>2</sup>	DN 32	32

\* Durchgangskörper und Abgang T-Körper (Y-Pos.)<sup>1</sup>

Gehäuseform	Code
Zweiwege-Durchgangskörper	D
T-Körper <sup>1</sup>	T

Anschlussart Ventilkörper	Code
Stutzen zum IR-Stumpfschweißen	20
Flare-Anschluss mit PVDF-Überwurfmutter	75
Flare-Anschluss mit PFA-Überwurfmutter	77
Armaturenverschraubung mit Einlegeteil DIN (IR-Stumpfschweißen)	78

Werkstoff Ventilkörper	Code
PP-H, grau <sup>2</sup>	G5
PP-R, natur <sup>2</sup>	R5
PVDF <sup>1</sup>	20
PFA, Perfluoralkoxy <sup>1</sup>	30




Dichtwerkstoff	Code
PTFE / EPDM, einteilig	54
PTFE/EPDM (verfügbar bis 01.12.2020)	5A

Steuerfunktion	Code
Manuell betätigt	0

Antriebsausführung	Code
<b>Standardausführung</b>	
Antriebsgröße 1 <sup>1</sup>	1
Antriebsgröße 2	2
Antriebsgröße 3	3
<b>Standardausführung mit ECTFE-Überwurfmutter*</b>	
Antriebsgröße 1 <sup>1</sup>	1E
Antriebsgröße 2 <sup>1</sup>	2E
Antriebsgröße 3 <sup>1</sup>	3E
<b>High Flow Ausführung</b>	
Antriebsgröße 2 <sup>1</sup>	2F
Antriebsgröße 3 <sup>1</sup>	3F
Antriebsgröße 2 <sup>1</sup> mit ECTFE-Überwurfmutter*	2EF
Antriebsgröße 3 <sup>1</sup> mit ECTFE-Überwurfmutter*	3EF

Bestimmung der Antriebsgröße: siehe Techn. Daten und Tabellen Seite 8 und 9.  
\* siehe Bezeichnung (6) auf Titelseite des Datenblattes C67 HPW

### Zusätzliche Bestellangaben für T-Ventile<sup>1</sup>

Position Space saver (für T-Körper) <sup>1</sup>	Code
Space saver in x-Position	 X
Space saver in z-Position	 Z
Space saver in x+z-Position	 S

Nennweite Durchgangsrohr (nur T-Ventile) <sup>1</sup>	Code	
1/2" Schlauch	DN 10	8
3/4" Schlauch	DN 15	12
1" Schlauch	DN 20	16
1" Rohr	DN 25	16
1 1/4" Schlauch	DN 25	20

Anschlussart Durchgangsrohr (nur T-Ventile) <sup>1</sup>	Code
Schweißstutzen Zoll	30
Flare-Anschluss mit CPFA-Überwurfmutter	73*
Flare-Anschluss mit PVDF-Überwurfmutter	75*
Flare-Anschluss mit PFA-Überwurfmutter	77*

\* auch für Space saver

Ausführung High Purity	Code
HP Smartline	HPS
High Purity, weiß	HPW

<sup>1</sup> nur Ausführung HPW  
<sup>2</sup> nur Ausführung HPS

Bestellbeispiel	C67	Z	8	D	75	30	5A	0	2	Z	8	75	HPW
Typ	C67												
Position Space saver (optional) <sup>1</sup>		Z											
Nennweite (Code)			8										
Gehäuseform (Code)				D									
Anschlussart Ventilkörper (Code)					75								
Werkstoff Ventilkörper (Code)						30							
Dichtwerkstoff (Code)							5A						
Steuerfunktion (Code)								0					
Antriebsausführung (Code)									2				
T-Körper: Position Space saver (optional) (Code) <sup>1</sup>		Z											
T-Körper: Nennweite Durchgangsrohr (Code) <sup>1</sup>			8										
T-Körper: Anschlussart Durchgangsrohr (Code) <sup>1</sup>												75	
Ausführung High Purity (Code)													HPW

## 8 Herstellerangaben

### 8.1 Transport

- Membranventil nur auf geeignetem Lademittel transportieren, nicht stürzen, vorsichtig handhaben.
- Verpackungsmaterial entsprechend den Entsorgungsvorschriften / Umweltschutzbestimmungen entsorgen.

#### Unterschied Ausführungen:

HPS: eingeschweißt in 1 PE-Folie  
HPW: eingeschweißt in 2 PE-Folien


### 8.2 Lieferung und Leistung

- Ware unverzüglich bei Erhalt auf Vollständigkeit und Unversehrtheit überprüfen.
- Lieferumfang aus Versandpapieren, Ausführung aus Bestellnummer ersichtlich.
- Das Membranventil wird im Werk auf Funktion geprüft.

### 8.3 Lagerung

- Membranventil staubgeschützt und trocken in Originalverpackung lagern.
- UV-Strahlung und direkte Sonneneinstrahlung vermeiden.
- Maximale Lagertemperatur: +40 °C.
- Lösungsmittel, Chemikalien, Säuren, Kraftstoffe u.ä. dürfen nicht mit Ventilen in einem Raum gelagert werden.

## 8.4 Benötigtes Werkzeug

VORSICHT	
	<b>Nur reinraumgeeignetes Werkzeug verwenden!</b> ➤ Kontaminationsgefahr!

- Benötigtes Werkzeug für Einbau und Montage ist **nicht** im Lieferumfang enthalten.
- Passendes, funktionsfähiges und sicheres Werkzeug benutzen.

## 8.5 Öffnen der Verpackung

Das Membranventil ist einfach (Ausführung HPS) bzw. zweifach (Ausführung HPW) in Plastikfolie verschweißt und in einen Karton verpackt.

VORSICHT
<b>Kartonverpackung nicht im Reinraum öffnen!</b> ➤ Kontaminationsgefahr!

VORSICHT
<b>Kartonverpackung außerhalb des Reinraums vorsichtig ohne Einsatz eines Messers oder spitzen Gegenstandes öffnen. Aufschlitzen der Plastikfolie vermeiden!</b> ➤ Kontaminationsgefahr! ➤ Herabsetzung des Produkt-Reinheitsgrads!

Kartonverpackung beinhaltet das eingeschweißte Membranventil.

## VORSICHT

**Ausführung HPW: Aufschlitzen der Plastikfolie vermeiden! Innere Plastikhülle aus Nylon-PE-Folie erst im Reinraum und unmittelbar vor Einbau öffnen!**

- Kontaminationsgefahr!
- Herabsetzung des Produkt-Reinheitsgrads!

## 9 Funktionsbeschreibung

GEMÜ CleanStar® C67 ist ein Kunststoff-Membranventil. Die außenliegenden Antriebsteile bestehen aus PVDF. Die Membrane besteht aus PTFE / EPDM. Standard sind optische Stellungsanzeige, integrierte Befestigungslaschen, Anschlussmöglichkeit für Leckagesensor und Schließkraftbegrenzung bzw. einstellbarer Mindestmengendurchfluss.

Unterschiede der Ausführungen:

### HPW:

- x hoher Reinheitsgrad
- x geeignet für High Purity Anwendungen / Reinraum
- x Durchgangs- und T-Körper verfügbar (PVDF: nur Durchgangskörper)
- x Ventilkörper aus PFA
- x Ventilkörper aus PVDF nur mit 1/2" Armaturenverschraubung

### HPS:

- x geringerer Reinheitsgrad als Ausführung HPW
- x geeignet für Anwendungen, die nicht dem High Purity Standard entsprechen müssen
- x Durchgangskörper verfügbar
- x Ventilkörper aus PP

Vielfältiges Zubehör ist lieferbar, z.B. Schlauchformdorn, Service-Werkzeug für Flare-Überwurfmuttern.




### Serviceschulungen auf Anfrage!

Zur Mitarbeiterschulung nehmen Sie bitte über die Adresse auf der letzten Seite Kontakt auf.

## 9.1 Typenschild


Geräteversion Ausführung gemäß Bestelldaten



Der Herstellungsmonat ist unter der Rückmeldenummer verschlüsselt und kann bei GEMÜ erfragt werden.

Das Produkt wurde in Deutschland hergestellt.

## 10 Geräteaufbau



Geräteaufbau

1 Ventilkörper

A Antrieb

## VORSICHT

**Ventilkörper und Antrieb nicht demontieren!**

- Gefahr von Undichtheit bzw. Defekt!
- Herstellerhaftung und Gewährleistungsanspruch erlischt.

# 11 Montage und Bedienung

## Vor Einbau:

- Ventilkörper- und Membranwerkstoff entsprechend Betriebsmedium auslegen.
- **Eignung vor Einbau prüfen!**  
Siehe Kapitel 6 "Technische Daten".

## 11.1 Montage des Membranventils

### ⚠️ WARNUNG

#### Unter Druck stehende Armaturen!

- Gefahr von schwersten Verletzungen oder Tod!
- Nur an druckloser Anlage arbeiten.

### ⚠️ WARNUNG



#### Aggressive Chemikalien!

- Verätzungen!
- Montage nur mit geeigneter Schutzausrüstung.
- Kontaminierte Anlagen ggf. dekontaminieren.

### ⚠️ VORSICHT



#### Heiße Anlagenteile!

- Verbrennungen!
- Nur an abgekühlter Anlage arbeiten.

### ⚠️ VORSICHT

#### Ventil nicht als Trittstufe oder Aufstiegshilfe benutzen!

- Gefahr des Abrutschens / der Beschädigung des Ventils.

### VORSICHT

#### Maximal zulässigen Druck nicht überschreiten!

- Eventuell auftretende Druckstöße (Wasserschläge) durch Schutzmaßnahmen vermeiden.

- Montagearbeiten nur durch geschultes Fachpersonal.

- Geeignete Schutzausrüstung gemäß den Regelungen des Anlagenbetreibers berücksichtigen.

## Installationsort:

### ⚠️ VORSICHT

- Ventil äußerlich nicht stark beanspruchen.
- Installationsort so wählen, dass Ventil nicht als Steighilfe genutzt werden kann.
- Rohrleitung so legen, dass Schub- und Biegekräfte, sowie Vibrationen und Spannungen vom Ventilkörper ferngehalten werden.
- Ventil nur zwischen zueinander passenden, fluchtenden Rohrleitungen montieren.

- x Richtung des Betriebsmediums: Beliebig.
- x Einbaulage des Membranventils: Beliebig.

## Montage:

1. Eignung des Ventils für jeweiligen Einsatzfall sicherstellen. Das Ventil muss für die Betriebsbedingungen des Rohrleitungssystems (Medium, Mediumkonzentration, Temperatur und Druck) sowie die jeweiligen Umgebungsbedingungen geeignet sein. Technische Daten des Ventils und der Werkstoffe prüfen.
2. Anlage bzw. Anlagenteil stilllegen.
3. Gegen Wiedereinschalten sichern.
4. Anlage bzw. Anlagenteil drucklos schalten.
5. Anlage bzw. Anlagenteil vollständig entleeren und abkühlen lassen bis Verdampfungstemperatur des Mediums unterschritten ist und Verbrühungen ausgeschlossen sind.
6. Anlage bzw. Anlagenteil fachgerecht dekontaminieren, spülen und belüften.
7. Anbau über serienmäßig angespritzte Befestigungslaschen.

## VORSICHT

**Befestigung mit geeigneten medienbeständigen Kunststoff-Schrauben (nicht im Lieferumfang enthalten)!**

- Korrosion und Kontamination bei Verwendung von Metall-Schrauben!

### Montage bei Schweißstutzen:

## ⚠ GEFAHR

**Austritt von extrem gesundheitsschädlichen Dämpfen beim Verschweißen von PFA!**

- Schädigung der Atemwege, Verätzung / Vergiftung!
- Absaugvorrichtung vor Schweißbeginn installieren.
- Nur zugelassene Schweißgeräte verwenden.
- Schutzausrüstung tragen.
- Zusätzlicher Atemschutz wird empfohlen.
- Durchführung der Schweißarbeiten nur durch qualifiziertes Fachpersonal.



### Wichtig:

Die Schweißung so durchführen, dass Beschädigungen (z.B. durch Überhitzung des Ventils / der Ventiltteile) ausgeschlossen sind. Folgen von Beschädigungen sind z.B. Undichtheit und Deformation.

### Schweißtechnische Normen einhalten!

### Montage bei Flare- und Space saver-Verbindungen:

1. Vorbereitung und Anschluss der Flare-Anschlüsse siehe auch GEMÜ FlareStar®-Prospekt und GEMÜ Flare- und Montageanleitung!
2. Aufgeweitetes Rohr vollständig auf Flare-Fittingkörper stecken.
3. Überwurfmutter darüber drehen.
4. Je nach Umgebungsbedingungen beständige und geeignete Anschlussfittings benutzen.

### Montage bei PrimeLock Verbindungen:

1. Vorbereitung des Schlauches durch Montage des Sleeves (Anleitung des Herstellers beachten: [www.entegrisfluidhandling.com / Product.aspx?G=1905](http://www.entegrisfluidhandling.com/Product.aspx?G=1905)).
2. PrimeLock Anschluss mit vorbereitetem Schlauch zusammen stecken.
3. PrimeLock Überwurfmutter anziehen.


### Entsprechende Vorschriften für Anschlüsse beachten!

### Nach der Montage:

- Alle Sicherheits- und Schutzeinrichtungen wieder anbringen bzw. in Funktion setzen.
- Eingebaute Ventile in regelmäßigen Abständen auf Funktion und Dichtheit prüfen.

## 11.2 Bedienung

### Optische Stellungsanzeige



Ventil offen



Ventil geschlossen

## ⚠ VORSICHT



### Heißes Handrad während Betrieb!


- Verbrennungen!
- Handrad nur mit Schutzhandschuhen betätigen.

## ⚠ VORSICHT

### Steigendes Handrad!

- Gefahr von Quetschungen der Finger.





### 11.3 Einstellung der Schließbegrenzung



**Wichtig:**

Einstellung der Schließbegrenzung nur bei komplett montiertem Ventil (mit Membrane und Ventilkörper) und in kaltem Zustand!

Zum Schutz der Dichtmembrane verfügen die Ventile der Baureihe GEMÜ CleanStar® C67 serienmäßig über eine mechanisch einstellbare Schließbegrenzung.


**Standardeinstellung:**

Das Ventil ist bei komplett zugedrehtem Handrad dicht.

**Einstellung der Schließbegrenzung:**

**Vorgehensweise:**

1. Arretierungsschraube **6** lösen, heraus drehen und entfernen.



2. Handrad **H** nach oben abziehen.

3. Einstellring **4** lösen, heraus drehen und entfernen.




4. Handrad **H** 180° verdreht auf den Vierkant der Antriebsspindel aufsetzen.



5. Ventil behutsam mit Handrad **H** schließen ("ZU").
6. Handrad **H** von Antriebsspindel abziehen.
7. Einstellring **4** auf die Antriebsspindel aufschrauben bis die Unterseite des Einstellrings **4** bündig am Ventiltrieb anliegt.



8. Handrad **H** in richtiger Position auf den Vierkant der Antriebsspindel aufstecken (Verzahnung des Einstellrings **4** und des Handrads **H** beachten). Mit Arretierungsschraube **6** befestigen.



## 11.4 Handradsicherung

### Beschreibung

Die Handradsicherung schützt gegen unbeabsichtigtes und unbefugtes Betätigen. Das Handrad kann in allen Positionen gegen unbeabsichtigte Betätigung gesichert werden. Die Handradsicherung besteht aus transparentem Kunststoff (PP), so dass die Handradstellung des Ventils zu erkennen ist. Verschiedene Farben sind lieferbar.



## 12 Inbetriebnahme

### ⚠️ WARNUNG



#### Aggressive Chemikalien!

- Verätzungen!
- Vor Inbetriebnahme Dichtheit der Medienanschlüsse prüfen!
- Dichtheitsprüfung nur mit geeigneter Schutzausrüstung.

### ⚠️ VORSICHT

#### Gegen Leckage vorbeugen!


- Schutzmaßnahmen gegen Überschreitung des maximal zulässigen Drucks durch eventuelle Druckstöße (Wasserschläge) vorsehen.

### Vor Reinigung bzw. vor Inbetriebnahme der Anlage:

- Membranventil auf Dichtheit und Funktion prüfen (Membranventil schließen und wieder öffnen).
- Bei neuen Anlagen und nach Reparaturen Leitungssystem bei voll geöffnetem Membranventil spülen (zum Entfernen schädlicher Fremdstoffe).


### Reinigung:

- x Betreiber der Anlage ist verantwortlich für Auswahl des Reinigungsmediums und Durchführung des Verfahrens.

	Beim Bestellen des Ventils komplette Bestellnummer angeben.
--	---

### 13 Inspektion und Wartung


<b>⚠️ WARNUNG</b>	
<b>Unter Druck stehende Armaturen!</b>	
<ul style="list-style-type: none"> <li>➤ Gefahr von schwersten Verletzungen oder Tod!</li> <li>● Nur an druckloser Anlage arbeiten.</li> </ul>	

<b>⚠️ VORSICHT</b>	
	<b>Heiße Anlagenteile!</b>
	<ul style="list-style-type: none"> <li>➤ Verbrennungen!</li> <li>● Nur an abgekühlter Anlage arbeiten.</li> </ul>

<b>⚠️ VORSICHT</b>	
<ul style="list-style-type: none"> <li>● Wartungs- und Instandhaltungstätigkeiten nur durch geschultes Fachpersonal.</li> <li>● Für Schäden welche durch unsachgemäße Handhabung oder Fremdeinwirkung entstehen, übernimmt GEMÜ keinerlei Haftung.</li> <li>● Nehmen Sie im Zweifelsfall vor Inbetriebnahme Kontakt mit GEMÜ auf.</li> </ul>	

1. Geeignete Schutzausrüstung gemäß den Regelungen des Anlagenbetreibers berücksichtigen.
2. Anlage bzw. Anlagenteil stilllegen.
3. Gegen Wiedereinschalten sichern.
4. Anlage bzw. Anlagenteil drucklos schalten.

Der Betreiber muss regelmäßige Sichtkontrollen der Ventile entsprechend den Einsatzbedingungen und des Gefährdungspotenzials zur Vorbeugung von Undichtheit und Beschädigungen durchführen.

	Der Betreiber der Anlage ist verantwortlich für die Einhaltung von Regelungen für spezielle Einsatzfälle.
---	---


### 14 Demontage

Demontage aus der Rohrleitung der Anlage erfolgt unter den gleichen Vorsichtsmaßnahmen wie die Montage.

- Membranventil demontieren (siehe Kapitel 11.1 "Montage des Membranventils").

<b>VORSICHT</b>	
<b>Ventilkörper und Antrieb nicht demontieren!</b>	
<ul style="list-style-type: none"> <li>➤ Gefahr von Undichtheit bzw. Defekt!</li> <li>➤ Herstellerhaftung und Gewährleistungsanspruch erlischt.</li> </ul>	

### 15 Entsorgung

	<ul style="list-style-type: none"> <li>● Membranventil vor Entsorgung spülen.</li> <li>● Alle Ventiltile entsprechend den Entsorgungsvorschriften / Umweltschutzbestimmungen entsorgen.</li> <li>● Auf Restanhaftungen und Ausgasung von eindiffundierten Medien achten.</li> </ul>
---	---

### 16 Rücksendung

- Membranventil reinigen.
- Rücksendeerklärung bei GEMÜ anfordern.
- Rücksendung nur mit vollständig ausgefüllter Rücksendeerklärung.

Ansonsten erfolgt keine  
 x Gutschrift bzw. keine  
 x Erledigung der Reparatur  
 sondern eine kostenpflichtige Entsorgung.

Daten des Typenschildes in  
Rücksendeerklärung eintragen:

C67 8T7530A12 1675/HPW ← Typ  
PB 6 bar  
ID-CH-88089374-047527 ← Serien-  
nummer

## 17 Hinweise



### Hinweis zur

### Mitarbeiterschulung:

Zur Mitarbeiterschulung nehmen Sie bitte über die Adresse auf der letzten Seite Kontakt auf.



### Hinweis zur Rücksendung:

Aufgrund gesetzlicher Bestimmungen zum Schutz der Umwelt und des Personals ist es erforderlich, dass die Rücksendeerklärung vollständig ausgefüllt und unterschrieben den Versandpapieren beiliegt. Nur wenn diese Erklärung vollständig ausgefüllt ist, wird die Rücksendung bearbeitet!

Im Zweifelsfall oder bei Missverständnissen ist die deutsche Version des Dokuments ausschlaggebend!

## 18 Fehlersuche / Störungsbehebung

Fehler	Möglicher Grund	Fehlerbehebung
Betriebsmedium entweicht aus Leckagebohrung* und / oder Handradgewindespindel (je nach Einbaulage)	Absperrmembrane defekt	Ventil austauschen
Ventil öffnet nicht bzw. nicht vollständig	Antrieb defekt	Ventil austauschen
Ventil im Durchgang undicht (schließt nicht bzw. nicht vollständig)	Betriebsdruck zu hoch	Ventil mit Betriebsdruck laut Datenblatt betreiben
	Fremdkörper zwischen Absperrmembrane und Ventilkörpersteg	Ventil austauschen
	Ventilkörpersteg beschädigt	Ventil austauschen
	Absperrmembrane defekt	Ventil austauschen
Verbindung Ventilkörper - Rohrleitung undicht	Schließbegrenzung** falsch eingestellt	Schließbegrenzung korrekt einstellen
	Unsachgemäße Montage	Montage Ventilkörper in Rohrleitung prüfen
Handrad lässt sich nicht drehen	Überwurfmuttern lose	Überwurfmuttern festziehen
	Antrieb defekt	Ventil austauschen

\* siehe Kapitel 10 "Geräteaufbau"

\*\* siehe Kapitel 11.3 "Einstellen der Schließbegrenzung"

# Konformitätserklärung

## Gemäß der Richtlinie 2014/68/EU

Wir, die Firma **GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG**  
**Fritz-Müller-Straße 6-8**  
**D-74653 Ingelfingen**

erklären, dass unten aufgeführte Armaturen die Sicherheitsanforderungen der Druckgeräterichtlinie 2014/68/EU erfüllen.

### Benennung der Armaturen - Typenbezeichnung

**Membranventil**  
GEMÜ C67


Benannte Stelle: TÜV Rheinland  
Berlin Brandenburg  
Nummer: 0035  
Zertifikat-Nr.: 01 202 926/Q-02 0036  
Angewandte Normen: AD 2000

Konformitätsbewertungsverfahren:  
**Modul H**

### Hinweis für Armaturen mit einer Nennweite $\leq$ DN 25:

Die Produkte werden entwickelt und produziert nach GEMÜ eigenen Verfahrensanweisungen und Qualitätsstandards, welche die Forderungen der ISO 9001 und der ISO 14001 erfüllen.

Die Produkte dürfen gemäß Artikel 4, Absatz 3 der Druckgeräterichtlinie 2014/68/EU keine CE- Kennzeichnung tragen.



Joachim Brien  
Leiter Bereich Technik

Ingelfingen-Criesbach, Juli 2016

# Contents

<b>1</b>	<b>General information</b>	<b>20</b>
<b>2</b>	<b>General safety information</b>	<b>20</b>
2.1	Information for service and operating personnel	20
2.2	Warning notes	21
2.3	Symbols used	21
<b>3</b>	<b>Definition of terms</b>	<b>22</b>
<b>4</b>	<b>Intended area of use</b>	<b>22</b>
<b>5</b>	<b>Scope of delivery</b>	<b>22</b>
<b>6</b>	<b>Technical data</b>	<b>22</b>
<b>7</b>	<b>Order data</b>	<b>28</b>
<b>8</b>	<b>Manufacturer's information</b>	<b>29</b>
8.1	Transport	29
8.2	Delivery and performance	29
8.3	Storage	29
8.4	Tools required	29
8.5	Opening the packaging	29
<b>9</b>	<b>Functional description</b>	<b>30</b>
9.1	Type plate	30
<b>10</b>	<b>Construction</b>	<b>30</b>
<b>11</b>	<b>Installation and operation</b>	<b>31</b>
11.1	Installing the diaphragm valve	31
11.2	Operation	32
11.3	Setting the seal adjuster	33
11.4	Lock out device	34
<b>12</b>	<b>Commissioning</b>	<b>34</b>
<b>13</b>	<b>Inspection and servicing</b>	<b>34</b>
<b>14</b>	<b>Disassembly</b>	<b>35</b>
<b>15</b>	<b>Disposal</b>	<b>35</b>
<b>16</b>	<b>Returns</b>	<b>35</b>
<b>17</b>	<b>Information</b>	<b>36</b>
<b>18</b>	<b>Troubleshooting / Fault clearance</b>	<b>36</b>
<b>19</b>	<b>EU Declaration of conformity</b>	<b>37</b>

## 1 General information

Prerequisites to ensure that the GEMÜ valve functions correctly:

- x Correct shipping and storage
- x Installation and commissioning by trained personnel
- x Operation according to the installation, operating and maintenance instructions
- x Recommended maintenance

Correct installation, operation, servicing and repair work ensure faultless diaphragm valve operation.



The descriptions and instructions apply to the standard versions. For special versions not described in these installation, operating and maintenance instructions the basic information contained herein applies in combination with any additional special documentation.



All rights including copyright and industrial property rights are expressly reserved.

## 2 General safety information

The safety information does not take into account:

- x Unexpected incidents and events, which may occur during installation, operation and servicing.
- x Local safety regulations which must be adhered to by the operator and by any additional installation personnel.

### 2.1 Information for service and operating personnel

The installation, operating and maintenance instructions contain fundamental safety information that must be observed during commissioning, operation and servicing. Non-compliance with these instructions may cause:

- x Personal hazard due to electrical, mechanical and chemical effects.
- x Hazard to nearby equipment.
- x Failure of important valve functions.
- x Hazard to the environment due to the leakage of dangerous materials.
- x Hazard to the process purity and / or the process system safety.



### Prior to commissioning:

- Read the installation, operating and maintenance instructions.
- Provide adequate training for the installation and operating personnel.
- Ensure that the contents of the installation, operating and maintenance instructions have been fully understood by the responsible personnel.
- Define the areas of responsibility.

### During operation:

- Keep the installation, operating and maintenance instructions available at the place of use.
- Observe the safety information.
- Use only in accordance with the specifications.
- Any servicing work and repairs not described in the installation, operating and maintenance instructions must not be performed without consulting the manufacturer first.

### **⚠ DANGER**

**Strictly observe the safety data sheets or the safety regulations that are valid for the media used.**

### In cases of uncertainty:

- x Consult the nearest GEMÜ sales office.

## 2.2 Warning notes

Wherever possible, warning notes are organised according to the following scheme:

### **⚠ SIGNAL WORD**

#### **Type and source of the danger**

- Possible consequences of non-observance.
- Measures for avoiding danger.

Warning notes are always marked with a signal word and sometimes also with a symbol for the specific danger.

The following signal words and danger levels are used:

### **⚠ DANGER**

#### **Imminent danger!**

- Non-observance will lead to death or severe injury.

### **⚠ WARNING**

#### **Potentially dangerous situation!**

- Non-observance can cause death or severe injury.

### **⚠ CAUTION**

#### **Potentially dangerous situation!**

- Non-observance can cause moderate to light injury.

### **CAUTION (WITHOUT SYMBOL)**

#### **Potentially dangerous situation!**

- Non-observance can cause damage to property.

## 2.3 Symbols used



Danger - hot surfaces!



Danger - corrosive materials!



Hand: indicates general information and recommendations.



Bullet point: indicates the tasks to be performed.



Arrow: indicates the response(s) to tasks.



Enumeration sign

### 3 Definition of terms

#### Working medium

The medium that flows through the diaphragm valve.

### 4 Intended area of use

- x The GEMÜ CleanStar® C67 diaphragm valve is designed for installation in piping systems. It controls a flowing medium by manual operation.
- x **The valve may only be used providing the product technical criteria are complied with (see chapter 6 "Technical data").**
- x Do not paint the bolts and plastic parts of the diaphragm valve!

#### **⚠ WARNING**

#### **Use the diaphragm valve only for the intended purpose!**

- Otherwise the manufacturer liability and guarantee will be void.
- Use the diaphragm valve only in accordance with the the operating conditions specified in the contract documentation and in the installation, operating and maintenance instructions.

### 5 Scope of delivery

The scope of delivery includes:

- x Diaphragm valve
- x For flare connections: Union nuts
- x Installation, operating and maintenance instructions

The GEMÜ diaphragm valve is supplied as a separately packed component.

### 6 Technical data

#### Working medium

Corrosive, inert, gaseous and liquid media (HPW version: particularly high purity media), which have no negative impact on the physical and chemical properties of the body and diaphragm material.  
High Flow version with improved Kv values.

#### Operating pressure

Max. 6 bar when applied upstream only

Vacuum 400 mbar/abs\*

\* The life expectancy of the valve may be affected if exposed to a greater vacuum.

#### Flow direction

Optional

#### Operating temperature

See temperature / pressure diagrams page 25

#### Ambient temperature

Max. 60 °C (130 °F)

#### Materials

HPS version: Media wetted parts (body)	PP
HPW version: Media wetted parts (body)	PFA
PVDF version: Media wetted parts (body)	PVDF
Diaphragm	PTFE
External bonnet parts	PVDF
HPW version: Union nut (bonnet-body), optional	ECTFE

#### PVDF version: Kv / Cv values - 2/2-way valves

Connection		Size		Kv value*	Cv value		
Size	Connection	Code	DN	Bonnet	l/min	US gal/min	
1/2"	Pipe	Union ends	7, 78	15	2	68.0	4.7

\* The measurement was carried out with water at 5 bar inlet pressure and a temperature of 20 °C.

HPW version: Kv / Cv values 2/2-way valves - standard

Connection						Kv	Cv	Bonnet size
Size		Connection	Code	Intern. code	DN	l/min	US gal/min	
1/4"	Tube	Flare connection	73, 75, 77	4	4	4	0.29	1
	Tube	Flare / Space Saver	73, 75, 77	4	4	4	0.29	1
	Tube	PrimeLock connection	PL	4	4	4	0.29	1
	Pipe	Imperial butt weld spigots	30	4	10	15	1.05	1
3/8"	Tube	Flare connection	73, 75, 77	6	6	15	1.05	1
	Tube	Flare / Space Saver	73, 75, 77	6	6	15	1.05	1
	Tube	PrimeLock connection	PL	6	6	15	1.05	1
1/2"	Tube	Flare connection	73, 75, 77	8	10	35	2.45	2
	Tube	Flare / Space Saver	73, 75, 77	8	10	35	2.45	2
	Tube	Space Saver / Space Saver	73, 75, 77	8	10	35	2.45	2
	Tube	PrimeLock connection	PL	8	10	35	2.45	2
	Tube/Pipe	Flare / Imperial butt weld spigots	30, 73, 75, 77	8	10/15	35	2.45	2
	Pipe	Imperial butt weld spigots	30	8	15	68	4.76	2
3/4"	Tube	Flare connection	73, 75, 77	12	15	68	4.76	2
	Tube	Flare / Space Saver	73, 75, 77	12	15	68	4.76	2
	Tube	Space Saver / Space Saver	73, 75, 77	12	15	68	4.76	2
	Tube/Pipe	Flare / Imperial butt weld spigots	30, 73, 75, 77	12	15/20	68	4.76	2
	Pipe	Imperial butt weld spigots	30	12	20	68	4.76	2
	Tube	Flare connection	73, 75, 77	12	15	68	4.76	3
	Tube/Pipe	Flare / Imperial butt weld spigots	30, 73, 75, 77	12	15/20	68	4.76	3
1"	Tube	Flare connection	73, 75, 77	16	20	158	11.06	3
	Tube	Flare / Space Saver	73, 75, 77	16	20	158	11.06	3
	Tube	Space Saver / Space Saver	73, 75, 77	16	20	158	11.06	3
	Tube/Pipe	Flare / Imperial butt weld spigots	30, 73, 75, 77	16	20/25	160	11.20	3
	Pipe	Imperial butt weld spigots	30	16	25	175	12.25	3
	1 1/4"	Tube	Flare connection*	73, 75, 77	20	25	170	11.90

2/2-way valves - High Flow

1/2"	Pipe	Imperial butt weld spigots	30	8	15	115	7.99	2
3/4"	Tube	PrimeLock connection	PL	12	15	115	7.99	2
	Tube	Flare / Space Saver	73, 75, 77	12	15	115	7.99	2
	Tube	Space Saver / Space Saver	73, 75, 77	12	15	115	7.99	2
	Tube	Flare connection	73, 75, 77	12	15	115	7.99	2
	Pipe	Imperial butt weld spigots	30	12	20	115	7.99	2
1"	Tube	PrimeLock connection	PL	16	20	123	8.57	2
	Tube	Flare connection	73, 75, 77	16	20	123	8.57	2
	Pipe	Imperial butt weld spigots	30	16	25	123	8.57	2
	Tube	PrimeLock connection	PL	16	20	316	21.99	3
	Tube	Flare connection	73, 75, 77	16	20	316	21.99	3
	Pipe	Imperial butt weld spigots	30	16	25	316	21.99	3
1 1/4"	Tube	PrimeLock connection	PL	20	25	170	11.90	3
	Tube	Flare connection	73, 75, 77	20	25	325	22.57	3

\* with welded spigots on request

Kv / Cv values - 2/2-way valves

Connection				Size			Kv value*	Cv value
Size		Connection	Code	International code	DN	Actuator	l/min	US gal/min
1/2"	Tube	Flare connection	75	8	10	2	34.2	2.4
	Pipe	Metric butt weld spigot	20	-	15	2	82.5	5.7
3/4"	Tube	Flare connection	75	12	15	2	86.7	6.0
	Pipe	Metric butt weld spigot	20	-	20	2	83.7	5.8
	Pipe	Metric butt weld spigot	20	-	20	3	171.7	11.9
1"	Tube	Flare connection	75	16	20	2	93.3	6.5
	Pipe	Metric butt weld spigot	20	-	25	2	94.0	6.5
	Tube	Flare connection	75	16	20	3	183.3	12.7
	Pipe	Metric butt weld spigot	20	-	25	3	233.3	16.2
	Pipe	Union ends with DIN insert	78	-	25	3	233.3	16.2
1 1/4"	Tube	Flare connection	75	20	25	3	238.3	16.6
	Pipe	Metric butt weld spigot	20	-	32	3	238.3	16.6


\* The measurement was carried out with water at 5 bar inlet pressure and a temperature of 20 °C.

HPW version: Kv / Cv values - T valves


HPW version: Kv / Cv values - T valves													
Main pipe X and Z						Branch Y					Bonnet	Kv value	Cv value
Connection				Size		Connection			Size				
Size		Connection	Code	Intern. code	DN	Size	Connection	Code	Intern. code	DN	Size	l/min	US gal/min
1/4"	Pipe	Imp. butt weld spigots	30	4	10	1/4" pipe	Imp. butt weld spigots	30	4	10	1		
3/8"	Tube	Flare connection	73, 75, 77	6	6	1/4" tube	Flare connection	73, 75, 77	4	4	1		
	Tube	Flare connection	73, 75, 77	6	6	3/8" tube	Flare connection	73, 75, 77	6	6	1		
1/2"	Tube	Flare connection	73, 75, 77	8	10	3/8" tube	Flare connection	73, 75, 77	6	6	1	17	1.19
	Tube	Flare / Space Saver	73, 75, 77	8	10	3/8" tube	Flare connection	73, 75, 77	6	6	1	17	1.19
	Tube	Flare connection	73, 75, 77	8	10	1/2" tube	Flare connection	73, 75, 77	8	10	2	28	1.96
	Tube	Flare / Space Saver	73, 75, 77	8	10	1/2" tube	Flare connection	73, 75, 77	8	10	2	28	1.96
	Tube	Space Saver / Flare	73, 75, 77	8	10	1/2" tube	Flare connection	73, 75, 77	8	10	2	28	1.96
	Pipe	Imp. butt weld spigots	30	8	15	1/4" pipe	Imp. butt weld spigots	30	4	10	1		
	Pipe	Imp. butt weld spigots	30	8	15	1/2" pipe	Imp. butt weld spigots	30	8	15	2		
	Pipe	Imp. butt weld spigots	30	8	15	1/2" tube	Space Saver	73, 75, 77	8	10	2	36	2,52
3/4"	Tube	Flare connection	73, 75, 77	12	15	3/8" tube	Flare connection	73, 75, 77	6	6	1	18	1.26
	Tube	Space Saver / Flare	73, 75, 77	12	15	3/8" tube	Flare connection	73, 75, 77	6	6	1	18	1.26
	Tube	Flare / Space Saver	73, 75, 77	12	15	3/8" tube	Flare connection	73, 75, 77	6	6	1	18	1.26
	Tube	Flare connection	73, 75, 77	12	15	1/2" tube	Flare connection	73, 75, 77	8	10	2	35	2.45
	Tube	Flare / Space Saver	73, 75, 77	12	15	1/2" tube	Flare connection	73, 75, 77	8	10	2	35	2.45
	Tube	Space Saver / Flare	73, 75, 77	12	15	1/2" tube	Flare connection	73, 75, 77	8	10	2	35	2.45
	Tube	Space Saver	73, 75, 77	12	15	1/2" tube	Flare connection	73, 75, 77	8	10	2	35	2.45
	Tube	Flare connection	73, 75, 77	12	15	1/2" tube	Space Saver	73, 75, 77	8	10	2	35	2.45
3/4"	Tube	Flare connection	73, 75, 77	12	15	3/4" tube	Flare connection	73, 75, 77	12	15	2	62	4.34
	Tube	Space Saver / Flare	73, 75, 77	12	15	3/4" tube	Flare connection	73, 75, 77	12	15	2	62	4.34
	Tube	Flare / Space Saver	73, 75, 77	12	15	3/4" tube	Flare connection	73, 75, 77	12	15	2	62	4.34
	Tube	Flare connection	73, 75, 77	12	15	3/4" tube	Space Saver	73, 75, 77	12	15	2	62	4.34
	Pipe	Imp. butt weld spigots	30	12	20	1/4" pipe	Imp. butt weld spigots	30	4	10	2		
	Pipe	Imp. butt weld spigots	30	12	20	1/2" pipe	Imp. butt weld spigots	30	8	15	2	38	2.66
	Pipe	Imp. butt weld spigots	30	12	20	1/2" tube	Flare connection	73, 75, 77	8	10	2	38	2.66
	Pipe	Imp. butt weld spigots	30	12	20	3/4" tube	Flare connection	73, 75, 77	12	15	2	71	4.97
1"	Tube	Flare connection	73, 75, 77	16	20	1/2" tube	Flare connection	73, 75, 77	8	10	2	38	2.66
	Tube	Space Saver / Flare	73, 75, 77	16	20	1/2" tube	Flare connection	73, 75, 77	8	10	2	38	2.66
	Tube	Flare / Space Saver	73, 75, 77	16	20	1/2" tube	Flare connection	73, 75, 77	8	10	2	38	2.66
	Tube	Space Saver	73, 75, 77	16	20	1/2" tube	Flare connection	73, 75, 77	8	10	2	38	2.66
	Tube	Flare connection	73, 75, 77	16	20	3/4" tube	Flare connection	73, 75, 77	12	15	2	71	4.97
	Tube	Space Saver / Flare	73, 75, 77	16	20	3/4" tube	Flare connection	73, 75, 77	12	15	2	71	4.97
	Tube	Flare / Space Saver	73, 75, 77	16	20	3/4" tube	Flare connection	73, 75, 77	12	15	2	71	4.97
	Tube	Flare connection	73, 75, 77	16	20	3/4" tube	Space Saver	73, 75, 77	12	15	2	71	4.97
	Tube	Flare connection	73, 75, 77	16	20	1" tube	Flare connection	73, 75, 77	16	20	3	137	9.59
	Tube	Space Saver / Flare	73, 75, 77	16	20	1" tube	Flare connection	73, 75, 77	16	20	3	137	9.59
	Tube	Flare / Space Saver	73, 75, 77	16	20	1" tube	Flare connection	73, 75, 77	16	20	3	137	9.59
	Pipe	Imp. butt weld spigots	30	16	25	1/2" pipe	Imp. butt weld spigots	30	8	15	3		
	Pipe	Imp. butt weld spigots	30	16	25	1/2" pipe	Flare connection	73, 75, 77	8	10	3		
	Pipe	Imp. butt weld spigots	30	16	25	3/4" pipe	Imp. butt weld spigots	30	12	20	3		
	Pipe	Imp. butt weld spigots	30	16	25	1" pipe	Imp. butt weld spigots	30	16	25	3	135	9.45
	Pipe	Imp. butt weld spigots	30	16	25	1" tube	Flare connection	73, 75, 77	16	20	3		
1 1/4"	Tube	Flare connection	73, 75, 77	20	25	1/2" tube	Flare connection	73, 75, 77	8	10	3	53	3.71
	Tube	Flare connection	73, 75, 77	20	25	3/4" tube	Flare connection	73, 75, 77	12	15	3	117	8.19
	Tube	Flare connection	73, 75, 77	20	25	1" tube	Flare connection	73, 75, 77	16	20	3	150	10.5
	Tube	Flare connection	73, 75, 77	20	25	1 1/4" tube	Flare connection	73, 75, 77	20	25	3	170	11.9

Kv / Cv value Flare connection ≙ Kv / Cv value Space saver


## Temperature / pressure diagram - Valve body material PFA (HPW version)



## Temperature / pressure diagram - Valve body material PP (HPS version)



## Temperature / pressure diagram - Valve body material PVDF (HPW version)



### Information on the use of the diagram

The temperature / pressure diagram is only an orientation aid. The data refer to water as a working medium. A change of operating conditions or other media may result in deviations. In case of doubt it is advisable to test the behavior of the material under the definitive operating conditions by means of a test installation.

Temperatures under 0 °C can affect the operating speed negatively.

RANGE OVERVIEW CleanStar® C67 HPW 2/2-WAY VALVES

Connection / availability							Size		Bonnet	Dimensions see data sheet page
Flare connection	PrimeLock	Butt weld spigots		Flare connection / Space saver			Connection			
		on both sides	on one side Pos. Z	on one side Pos. X	on one side Pos. Z	on both sides Pos. X + Z	International code	DN		
1/4" - 1/4"	1/4" - 1/4"	1/4" - 1/4"			1/4" - 1/4"		4	4/10	1	9
3/8" - 3/8"	3/8" - 3/8"				3/8" - 3/8"		6	6		9
1/2" - 1/2"	1/2" - 1/2"				1/2" - 1/2"	1/2" - 1/2"	8	10	2	10
		1/2" - 1/2" <sup>2</sup>	1/2" - 1/2"				8	10/15		10
3/4" - 3/4" <sup>2</sup>	3/4" - 3/4" <sup>1</sup>				3/4" - 3/4"	3/4" - 3/4"	12	15		10
			3/4" - 3/4"				12	15/20		10
		3/4" - 3/4" <sup>2</sup>					12	20		10
1" - 1" <sup>1</sup>	1" - 1" <sup>1</sup>						16	20	10	
3/4" - 3/4"							12	15	3	11
			3/4" - 3/4"				12	15/20		11
		3/4" - 3/4"					12	20		11
1" - 1" <sup>2</sup>	1" - 1" <sup>1</sup>				1" - 1"	1" - 1"	16	20		11
		1" - 1" <sup>2</sup>					16	25		11
			1" - 1"				16	20/25	11	
1 1/4" - 1 1/4" <sup>2</sup>	1 1/4" - 1 1/4" <sup>1</sup>				1 1/4" - 1 1/4" <sup>2</sup>	1 1/4" - 1 1/4" <sup>2</sup>	20	25	11	

<sup>1</sup> only High Flow version

<sup>2</sup> High Flow version with increased Kv value

RANGE OVERVIEW CleanStar® C67 HPS 2/2-WAY VALVES

Connection / availability							Actuator size	Dimensions see Page
Flare connection	Butt weld spigot		Union ends with DIN insert	Connection		C67		
	on both sides	on one side Pos. Z		Code international	DN			
1/2" - 1/2"			8	10	2	7		
	15 - 15		-	15		7		
3/4" - 3/4"			12	15		7		
	20 - 20		-	20		7		
1" - 1"			16	20		7		
	25 - 25		-	25	7			
	20 - 20			20	3	7		
1" - 1"			16	25		7		
	25 - 25		-	25		7		
			25 - 25	25		8		
1 1/4" - 1 1/4"			20	25		7		
	32 - 32		-	32	7			



RANGE OVERVIEW CleanStar® C67 HPW T VALVES

Connection / availability					Size				Bonnet	Dimensions see data sheet page
Flare connection	Flare connection / space saver				Connection					
	Main pipe				Main pipe X + Z		Branch Y			
	Pos. X	Pos. Z	Pos. X + Z	Pos. Y	International code	DN	International code	DN		
									International code	DN
3/8" 1/4" 3/8"					6	6	4	4	1	12
3/8" 3/8" 3/8"					6	6	6	6		12
1/2" 3/8" 1/2"					8	10	6	6		12
3/4" 3/8" 3/4"	3/4" 3/8" 3/4"	3/4" 3/8" 3/4"			12	15	6	6		12
1/2" 1/2" 1/2"		1/2" 1/2" 1/2"		1/2" 1/2" 1/2"	8	10	8	10	2	13/14
					8	15	8	15		13/14
					8	15	8	10		13/14
3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	3/4" 1/2" 3/4"	12	15	8	10		13/14
					12	20	4	8		13/14
3/4" 3/4" 3/4"	3/4" 3/4" 3/4"	3/4" 3/4" 3/4"		3/4" 3/4" 3/4"	12	15	12	15		13/14
1" 1/2" 1"	1" 1/2" 1"	1" 1/2" 1"	1" 1/2" 1"		16	20	8	10		13/14
1" 3/4" 1"	1" 3/4" 1"	1" 3/4" 1"		1" 3/4" 1"	16	20	12	15	13/14	
					16	25	8	15	3	15
					16	25	12	20		15
					16	25	16	25		15
1" 1" 1"	1" 1" 1"	1" 1" 1"			16	20	16	20		15
1 1/4" 1/2" 1 1/4"		1 1/4" 1/2" 1 1/4"			20	25	8	10		15
1 1/4" 3/4" 1 1/4"		1 1/4" 3/4" 1 1/4"			20	25	12	15		15
1 1/4" 1" 1 1/4"		1 1/4" 1" 1 1/4"			20	25	16	20		15
1 1/4" 1 1/4" 1 1/4"		1 1/4" 1 1/4" 1 1/4"			20	25	20	25	15	

RANGE OVERVIEW CleanStar® C67 HPW T VALVES

Connection / availability				Size				Bonnet	Dimensions see data sheet page
Butt weld spigot	Butt weld spigot / flare connection	Butt weld spigot / space saver	Butt weld spigot / flare connection	Connection					
				Main pipe X + Z		Branch Y			
				International code	DN	International code	DN		
1/4" 1/4" 1/4"				4	10	4	10	1	12
1/2" 1/4" 1/2"				8	15	4	8		12
1/2" 1/2" 1/2"				8	15	8	15	2	13/14
		1/2" 1/2" 1/2"	1/2" 1/2" 1/2"	8	15	8	10		13/14
	3/4" 1/2" 3/4"			12	20	8	10		13/14
	3/4" 3/4" 3/4"			12	20	12	15		13/14
3/4" 1/4" 3/4"				12	20	4	8		13/14
3/4" 1/2" 3/4"				12	20	8	15	13/14	
1" 1/2" 1"								3	15
1" 3/4" 1"									15
1" 1" 1"									15
	1" 1/2" 1"	1" 1/2" 1"		16	25	8	10		15
	1" 1" 1"	1" 1" 1"		16	25	10	20	15	

## 7 Order data

Position space saver <sup>1</sup> (for 2/2-way body)		Code
Space saver in z-position		Z
Space saver in x+z-position		S

Position butt weld spigot <sup>1</sup> (for 2/2-way body)		Code
Flare in x, butt weld spigot in z		K

Position space saver <sup>1</sup> (for T body)		Code
Space saver in y-position		Y

Nominal size*		Code
1/4" tube <sup>1</sup>	DN 4	4
3/8" tube <sup>1</sup>	DN 6	6
1/2" tube	DN 10	8
1/2" pipe	DN 15	8
3/4" tube	DN 15	12
3/4" pipe <sup>1</sup>	DN 20	12
Pipe <sup>2</sup>	DN 15	15
1" tube	DN 20	16
1" pipe <sup>1</sup>	DN 25	16
1 1/4" tube	DN 25	20
Pipe <sup>2</sup>	DN 20	20
Pipe <sup>2</sup>	DN 25	25
Pipe <sup>2</sup>	DN 32	32

\* 2/2-way body and branch of T body (Y-pos.)<sup>1</sup>

Body configuration	Code
2/2-way body	D
T body <sup>1</sup>	T

Valve body connection	Code
Spigots for IR butt welding	20
Flare connection with PVDF union nut	75
Flare connection with PFA union nut	77
Union ends with DIN insert (for IR butt welding)	78

Valve body material	Code
PP-H, grey <sup>2</sup>	G5
PP-R, natural <sup>2</sup>	R5
PVDF <sup>1</sup>	20
PFA, perfluoralkoxy <sup>1</sup>	30

<sup>1</sup> only HPW version  
<sup>2</sup> only HPS version

Diaphragm material	Code
PTFE / EPDM, one-piece	54
PTFE/EPDM (available until 01.12.2020)	5A

Control function	Code
Manually operated	0

Bonnet version	Code
<b>Standard version</b>	
Bonnet size 1 <sup>1</sup>	1
Bonnet size 2	2
Bonnet size 3	3
<b>Standard version with ECTFE union nut*</b>	
Bonnet size 1 <sup>1</sup>	1E
Bonnet size 2 <sup>1</sup>	2E
Bonnet size 3 <sup>1</sup>	3E
<b>High Flow Version</b>	
Bonnet size 2 <sup>1</sup>	2F
Bonnet size 3 <sup>1</sup>	3F
Bonnet size 2 <sup>1</sup> with ECTFE union nut*	2EF
Bonnet size 3 <sup>1</sup> with ECTFE union nut*	3EF

For defining the bonnet size: see Techn. Data and tables on pages 26 and 27.  
\* see designation (6) on title page of data sheet C67 HPW

### Additional order data for T valves<sup>1</sup>

Position of space saver (for T body) <sup>1</sup>	Code
Space saver in x-position	X
Space saver in z-position	Z
Space saver in x+z-position	S

Nominal size of main pipe (only T valves) <sup>1</sup>		Code
1/2" tube	DN 10	8
3/4" tube	DN 15	12
1" tube	DN 20	16
1" pipe	DN 25	16
1 1/4" tube	DN 25	20

Connection of main pipe (only T valves) <sup>1</sup>		Code
Imperial butt weld spigots		30
Flare connection with CPFA union nut		73*
Flare connection with PVDF union nut		75*
Flare connection with PFA union nut		77*

\* also for space saver

High Purity version	Code
HP Smartline	HPS
High Purity, white	HPW

Order example	C67	Z	8	D	75	30	5A	0	2	Z	8	75	HPW
Type	C67												
Position space saver (optional) <sup>1</sup>		Z											
Nominal size (code)			8										
Body configuration (code)				D									
Valve body connection (code)					75								
Valve body material (code)						30							
Seal material (code)							5A						
Control function (code)								0					
Bonnet version (code)									2				
T body: Position of space saver (optional) (code) <sup>1</sup>		Z											
T body: Nominal size of main pipe (code) <sup>1</sup>			8										
T body: Connection of main pipe (code) <sup>1</sup>												75	
High Purity version (code)													HPW

## 8 Manufacturer's information

### 8.1 Transport

- Only transport the diaphragm valve by suitable means. Do not drop. Handle carefully.
- Dispose of packing material according to relevant local or national disposal regulations / environmental protection laws.

#### Difference between versions:

HPS: Sealed in 1 PE plastic bag

HPW: Sealed in 2 PE plastic bags

### 8.2 Delivery and performance

- Check that all parts are present and check for any damage immediately upon receipt.
- The scope of delivery is apparent from the dispatch documents and the design from the order number.
- The performance of the diaphragm valve is checked at the factory.

### 8.3 Storage

- Store the diaphragm valve free from dust and moisture in its original package.
- Avoid UV rays and direct sunlight.
- Maximum storage temperature: +40 °C.
- Solvents, chemicals, acids, fuels or similar fluids must not be stored in the same room as valves and their spare parts.

### 8.4 Tools required

CAUTION	
	<p><b>Only use tools suitable for cleanrooms!</b></p> <p>➤ Contamination risk!</p>

- The tools required for installation and assembly are **not** included with this valve.
- Use appropriate, functional and safe tools.

### 8.5 Opening the packaging

The diaphragm valve is sealed in a single plastic bag (HPS version) or two plastic bags (HPW version) and packed in a box.

CAUTION
<p><b>Do not open box in the cleanroom!</b></p> <p>➤ Contamination risk!</p>

CAUTION
<p><b>Carefully open box outside the cleanroom. Do not use a knife or pointed object. Avoid tearing open the plastic bag!</b></p> <p>➤ Contamination risk!</p> <p>➤ Reduces product purity!</p>

Labeled GEMÜ box contains the sealed diaphragm valve.

## CAUTION

### HPW version:

**Avoid tearing open the plastic bag!  
Only open internal Nylon-PE plastic bag in the cleanroom immediately prior to installation!**

- Contamination risk!
- Reduces product purity!

## 9 Functional description

The GEMÜ CleanStar® C67 is a plastic diaphragm valve. The external bonnet parts are made of PVDF. The diaphragm is made of PTFE / EPDM. Optical position indicator, integrated mounting base with flexible slots, leak detection port and a travel stop are standard features.

Difference between versions:

### HPW:

- x High level of purity
- x Suitable for High Purity applications / cleanroom
- x 2/2-way and T bodies available (PVDF: only 2/2-way bodies)
- x Valve body in PFA
- x Valve body in PVDF only with 1/2" union ends

### HPS:

- x Lower level of purity than for HPW version
- x Suitable for applications that need not comply with High Purity standards
- x 2/2-way body available
- x Valve body in PP

Diverse accessories are available, such as flaring mandrel, service tool for flare union nuts.



### Service training on request!

Please contact us at the address on the last page for staff training information.


## 9.1 Type plate

Device version		Design in accordance with order data	
		Device-specific data	
GEMÜ Fritz-Müller-Str. 6-8 D-74653 Ingellingen	C60	8D75G55A1	2
	HPS	PS 6,0 bar	
	PST	4,0- 7,0 bar	
	ERE DE	2020	
	88333374		12103529   0001
Item number	Traceability number		Serial number

The month of manufacture is encoded in the traceability number and can be obtained from GEMÜ.

The product was manufactured in Germany.

## 10 Construction



Construction

1 Valve body

A Bonnet

## CAUTION

**Do not disassemble valve body and bonnet!**

- Danger of leakage or defect!
- Manufacturer's warranty will be voided.


# 11 Installation and operation


## Prior to installation:

- Ensure that valve body and diaphragm material are appropriate and compatible to handle the working medium.
- **Check the suitability prior to the installation.**  
See chapter 6 "Technical data".

## 11.1 Installing the diaphragm valve

<b>⚠ WARNING</b>	
<b>The equipment is subject to pressure!</b>	
➤ Risk of severe injury or death!	
● Only work on depressurized plant.	

<b>⚠ WARNING</b>	
	<b>Corrosive chemicals!</b>
	➤ Risk of caustic burns!
	● Wear appropriate personal protective gear when installing.
	● Flush and rinse contaminated installations as necessary.

<b>⚠ CAUTION</b>	
	<b>Hot plant components!</b>
	➤ Risk of burns!
	● Only work on plant that has cooled down.

<b>⚠ CAUTION</b>	
<b>Never use the valve as a step or an aid for climbing!</b>	
➤ This entails the risk of slipping-off or damaging the valve.	

<b>CAUTION</b>	
<b>Do not exceed the maximum permissible pressure!</b>	
➤ Take precautionary measures to avoid possible pressure surges (water hammer).	

- Installation work must only be performed by trained personnel.
- Use appropriate protective gear as

specified in plant operator's guidelines.

## Installation location:

<b>⚠ CAUTION</b>	
● Do not apply external force to the valve.	
● Choose the installation location so that the valve cannot be used as a foothold (climbing aid).	
● Lay the pipeline so that the valve body is protected against transverse and bending forces, and also vibrations and tension.	
● Only mount the valve between matching aligned pipes.	

- x Direction of the working medium: optional.
- x Mounting position of the diaphragm valve: optional.

## Installation:

1. Ensure the suitability of the valve for each respective use. The valve must be appropriate for the piping system operating conditions (medium, medium concentration, temperature and pressure) and the prevailing ambient conditions. Check the technical data of the valve and the materials.
2. Shut off plant or plant component.
3. Secure against recommissioning.
4. Depressurize the plant or plant component.
5. Completely drain the plant (or plant component) and let it cool down until the temperature is below the media vaporization temperature and scalding can be ruled out.
6. Correctly decontaminate, rinse and ventilate the plant or plant component.
7. Mounting via flexible slots in valve base.

<b>CAUTION</b>	
<b>Fix the valve with suitable media resistant plastic bolts (not included in the scope of delivery)!</b>	
➤ Corrosion and contamination when using metal bolts!	

## Installation - Butt weld spigots:

### **⚠ DANGER**

#### **Vapor fumes from PFA welding can cause health related issues!**

- Risk of damage to respiratory tracts, caustic burns / poisoning!
- Weld PFA components in a well-ventilated area.
- Only use approved welding equipment.
- Wear protective gear.
- Breathing masks are recommended.
- Welding may only be carried out by qualified trained personnel.



#### **Important:**

Poor or careless welding procedures and processes will void warranty and cause damage to the product. The results of poor welding procedures are valve leakage and deformation.

## Adhere to good welding practices!

### Installation - Flare and space saver connections:

1. Also refer to GEMÜ FlareStar® brochure and GEMÜ flare and assembly instructions for preparation and connection of flare connections!
2. Push the flared tube onto the flare connection.
3. Screw on union nut.
4. Use connection fittings resistant to and suitable for the ambient conditions.

### Installation - PrimeLock connections:

1. Preparation of the tube by mounting the sleeve (observe manufacturer's instructions:  
[www.entegrisfluidhandling.com / Product.aspx?G=1905](http://www.entegrisfluidhandling.com/Product.aspx?G=1905).)
2. Push together PrimeLock connection with prepared tube.
3. Tighten PrimeLock union nut.


## Observe appropriate regulations for connections!

## After the installation:

- Reactivate all safety and protective devices.
- Check the function and tightness of installed valves at regular intervals.

## 11.2 Operation

### Optical position indicator



### **⚠ CAUTION**




#### **Handwheel can become hot during operation!**

- Risk of burns!
- Ensure protective gloves are worn when operating handwheel.

### **⚠ CAUTION**

#### **Rising handwheel!**

- Danger of crushing fingers.





## 11.3 Setting the seal adjuster



### Important:

Only set the seal adjuster when the valve is completely assembled (with diaphragm and valve body) and in a cold condition!

The GEMÜ CleanStar® C67 valves have a mechanical seal adjuster as standard to protect the sealing diaphragm.


### Standard setting:

The valve is sealed when the handwheel is completely closed (turned fully clockwise).

### Setting the seal adjuster:

#### Procedure:

1. Unscrew the locking screw **6** and remove it.



2. Pull off the handwheel **H**.
3. Unscrew the adjusting ring **4** and remove it.



4. Place the handwheel **H** upside down on the square of the bonnet spindle.




5. Close the valve gently by turning handwheel **H** ("CLOSED").
6. Pull off handwheel **H** from the bonnet spindle.
7. Screw the adjusting ring **4** onto the bonnet spindle until the bottom side of the adjusting ring **4** sits on the face of the valve bonnet.



8. Push handwheel **H** in its original position on the square of the bonnet spindle (observe the teeth of the adjusting ring **4** and the handwheel **H**).

Tighten it with locking screw 6.



## 11.4 Lock out device

### Description

The lock out device secures the valve against accidental or unauthorized operation. The handwheel can be secured in all positions against accidental operation. The lock out device is made of transparent plastic (PP) so that the position of the handwheel is visible. Various colors are available.



## 12 Commissioning

### ⚠ WARNING



#### Corrosive chemicals!

- Risk of caustic burns!
- Check the tightness of the media connections prior to commissioning!
- Use only the appropriate protective gear when performing the tightness check.

### ⚠ CAUTION

#### Protect against leakage!

- Provide precautionary measures against exceeding the maximum permitted pressures caused by pressure surges (water hammer).

#### Prior to cleaning or commissioning the plant:

- Check the tightness and the function of the diaphragm valve (close and reopen the diaphragm valve).
- If the plant is new and after repairs rinse the piping system with a fully opened diaphragm valve (to remove any harmful foreign matter).

#### Cleaning:

- x The plant operator is responsible for selecting the cleaning material and performing the procedure.

## 13 Inspection and servicing

### ⚠ WARNING

#### The equipment is subject to pressure!

- Risk of severe injury or death!
- Only work on depressurized plant.

### ⚠ CAUTION



#### Hot plant components!

- Risk of burns!
- Only work on plant that has cooled down.

## ▲ CAUTION

- Servicing and maintenance work may only be performed by trained personnel.
- GEMÜ shall assume no liability whatsoever for damages caused by improper handling or third-party actions.
- In case of doubt, contact GEMÜ before commissioning.

1. Use appropriate protective gear as specified in plant operator's guidelines.
2. Shut off plant or plant component.
3. Secure against recommissioning.
4. Depressurize the plant or plant component.

The operator must carry out regular visual examination of the valves dependent on the operating conditions and the potential danger in order to prevent leakage and damage.



The operator of the plant is responsible for compliance with regulations for special applications.



When ordering the valve, please state the complete order number.

## 14 Disassembly

Disassembly is performed observing the same precautionary measures as for installation.

- Disassemble the diaphragm valve (see chapter 11.1 "Installing the diaphragm valve").

## CAUTION

**Do not disassemble valve body and bonnet!**

- Danger of leakage or defect!
- Manufacturer's warranty will be voided.

## 15 Disposal



- Fully rinse the diaphragm valve before disposal.
- All valve parts must be disposed of according to relevant local or national disposal regulations / environmental protection laws.
- Pay attention to adhered residual material and gas diffusion from penetrated media.

## 16 Returns

- Clean the diaphragm valve.
- Request a goods return declaration form from GEMÜ.
- Returns must be made with a completed declaration of return.

If not completed, GEMÜ cannot process  
x credits or  
x repair work  
but will dispose of the goods at the operator's expense.

Enter data from the product label on the declaration of return:


C67 8T7530A12 1675/HPW ← Type  
PB 6 bar  
ID-CH-88089374-047527 ← Serial number



### Note for returns:

Legal regulations for the protection of the environment and personnel require that the completed and signed goods return declaration is included with the dispatch documents. Returned goods can be processed only when this declaration is completed.

## 17 Information

	<p><b>Note on staff training:</b> Please contact us at the address on the last page for staff training information.</p>
--	---

Should there be any doubts or misunderstandings in the preceding text, the German version of this document is the authoritative document!

## 18 Troubleshooting / Fault clearance

Fault	Possible cause	Fault clearance
Working medium escapes from leak detection port* and / or threaded handwheel spindle (dependent on mounting position)	Diaphragm faulty	Replace valve
Valve doesn't open or doesn't open fully	Bonnet faulty	Replace valve
Valve leaks downstream (doesn't close or doesn't close fully)	Operating pressure too high	Operate valve with operating pressure specified in data sheet
	Foreign matter between diaphragm and valve body weir	Replace valve
	Valve body weir damaged	Replace valve
	Diaphragm faulty	Replace valve
	Travel stop** incorrectly set	Correctly adjust travel stop
Valve body connection to piping leaks	Incorrect installation	Check installation of valve body in piping
	Union nuts loose	Tighten union nuts
Handwheel cannot be turned	Bonnet faulty	Replace valve

\* see chapter 10 "Construction"

\*\* see chapter 11.3 "Setting the seal adjuster"

# Declaration of Conformity

## According to annex VII of the Directive 2014/68/EU

Hereby we, **GEMÜ Gebr. Müller Apparatebau GmbH & Co. KG**  
**Fritz-Müller-Straße 6-8**  
**D-74653 Ingelfingen**

declare that the equipment listed below complies with the safety requirements of the Pressure Equipment Directive 2014/68/EU.

### Description of the equipment - product type

**Diaphragm Valve**  
**GEMÜ C67**


Notified body: TÜV Rheinland  
Berlin Brandenburg  
Number: 0035  
Certificate no.: 01 202 926/Q-02 0036  
Applied standards: AD 2000

Conformity assessment procedure:  
**Module H**

### Note for equipment with a nominal size $\leq$ DN 25:

The products are developed and produced according to GEMÜ process instructions and quality standards which comply with the requirements of ISO 9001 and of ISO 14001.

According to section 4, paragraph 3 of the Pressure Equipment Directive 2014/68/EU these products must not be identified by a CE-label.



Joachim Brien  
Head of Technical Department

Ingelfingen-Criesbach, July 2016







---

**GEMÜ®**



Änderungen vorbehalten · Subject to alteration · 01/2020 · 88248918